



PP: patch pannel

In the regular HRS electronics, the cables from PP3 go to HRS ADCs. For the PVDIS setup there is a longer loop for this connection.

The positions of PP1 and PP2 are fake here, but they exist in reality.