

# High Voltage Output Module

The high voltage output module is located in the injector service building against the back wall in Zone 1. It is also adjacent to the stairwell which goes into the injector tunnel. The output module is inside a bright yellow plastic container which help limit oil leaks. The output module itself is a large, sealed canister with connection points on the top. The yellow bin is interlocked, and the lock on the front is opened with the kirk key from the knife switch.



Fig. 1: The exterior of the yellow bin which contains the high voltage output module.



Fig. 2: The high voltage output module inside the yellow bin.