

April 14, 2009			
Drawing Number	Title	Revision Level	Revision Date
05300-D-0001			
05300-D-0002	PSS OVERVIEW BLOCK DIAGRAM	NO DWG	
05300-D-2001	ITS / CMTF PSS KEY - LOCK CHASSIS	NO DWG	
05300-D-2002	ITS / CMTF PSS STATUS SCHEMATIC	NO DWG	
05300-D-2003	PSS CHASSIS SCHEMATIC	NO DWG	
05300-D-2004	PSS P.A. CHASSIS SCHEMATIC	NO DWG	
05300-D-2005	PSS SYS STATUS CHASSIS SCHEMATIC	NO DWG	
05300-D-2006	PSS U.I.B. CHASSIS SCHEMATIC	NO DWG	
05300-D-2007	PSS LASER SHUTTER SCHEMATIC	NO DWG	
05301-D-0001	FEL / PSS RACK LAYOUT - MCC EQUIPMENT ROOM	E	Sep-97
05302-D-0001	FEL / PSS RACK LAYOUT - FEL FACILITY	D	Mar-01
05303-D-0001	FEL DOOR LOCK / KEY EXCHANGE CONTROL PANEL ASSEMBLY AND FABRICATION DETAILS	A	Jun-04
05304-D-0001	FEL DOOR LOCK / KEY EXCHANGE CONTROL PANEL WIRING DIAGRAM	B	Oct-06
05305-D-0001	FEL / PSS KEYSWITCH CONTROL PANEL ASSEMBLY & FABRICATION DETAILS	B	Jun-04
05306-D-0001	FEL / PSS KEYSWITCH CONTROL PANEL WIRING DIAGRAM	B	Sep-04
05307-D-0001	FEL / PSS RUN /SAFE BOX LOCATION SITE LAYOUT	D	Aug-07
05308-D-0001	FEL / PSS RUN / SAFE BOX WIRING DIAGRAM	C	Aug-07
05309-D-0001	FEL / PSS ODH SYSTEM SITE LAYOUT	P	Feb-09
05310-D-0001	FEL / PSS ODH WIRING DIAGRAM	R	Apr-09
05311-D-0001	FEL / PSS INTERCOM SYSTEM SITE LAYOUT	D	Jun-04
05312-D-0001	FEL / PSS INTERCOM SYSTEM WIRING DIAGRAM	NO DWG	
05313-D-0001	FEL / PSS RADIATION MONITORS LOCATION SITE LAYOUT	E	Jul-97

April 14, 2009			
Drawing Number	Title	Revision Level	Revision Date
05314-D-0001	FEL / PSS RADIATION MONITORS INTERLOCK WIRING DIAGRAM	C	Jun-98
05315-D-0001	FEL / PSS RADIATION MONITORS RS-485 BUS SYSTEM WIRING DIAGRAM	A	Nov-97
05316-D-0001	FEL / PSS FEL ACCESS ROOM INTERLOCK WIRING DIAGRAM	B	Oct-97
05317-D-0001	FEL / PSS FEL ACCESS ROOM EQUIPMENT LAYOUT	NO DWG	
05318-D-0001	STATUS DISPLAY SYSTEM - FEL FACILITY WIRING DIAGRAM	H	Oct-08
05319-D-0001	FEL / PSS I/O ALLOCATION-SYSTEM A-MCC FEL RACK	-	Apr-97
05320-D-0001	FEL / PSS I/O ALLOCATION-SYSTEM B-MCC FEL RACK	-	Apr-97
05321-D-0001	FEL / PSS I/O ALLOCATION-SYSTEM A-FEL RACK	B	Jul-99
05322-D-0001	FEL / PSS I/O ALLOCATION-SYSTEM B-FEL RACK	B	Jul-99
05323-D-0001	FEL TRUCK RAMP - INTERLOCK WIRING	F	Feb-08
05324-D-0001	TYPICAL 32 CHANNEL OUTPUT MODULE TO CROSS CONNECT CABLING	-	Feb-97
05325-D-0001	TYPICAL 32 CHANNEL INPUT MODULE TO CROSS CONNECT CABLING	-	Feb-97
05326-D-0001	FEL GUN / SAFETY INTERFACE - WIRING DIAGRAM	C	May-98
05327-D-0001	FEL GUN / SAFETY INTERFACE CHASSIS - WIRING DIAGRAM	C	Nov-97
05328-D-0001	FEL GUN / SAFETY INTERFACE CHASSIS - ASSEMBLY DIAGRAM	-	Apr-97
05329-D-0001	FEL GUN / SAFETY INTERFACE CHASSIS - FABRICATION DIAGRAM	-	Apr-97
05330-D-0001	LASER SHUTTER / SAFETY INTERFACE - WIRING DIAGRAM	B	Dec-97
05331-D-0001	LASER SHUTTER / SAFETY INTERFACE CHASSIS - WIRING DIAGRAM	C	Nov-97
05332-D-0001	FEL LASER SHUTTER / SAFETY INTERFACE CHASSIS ASSEMBLY DIAGRAM	B	Nov-97

April 14, 2009			
Drawing Number	Title	Revision Level	Revision Date
05333-D-0001	FEL LASER SHUTTER / SAFETY INTERFACE CHASSIS FABRICATION DIAGRAM	A	Nov-97
05334-D-0001	FEL MAGNET / SAFETY INTERFACE - WIRING DIAGRAM	D	Jan-08
05335-D-0001	RF / SAFETY INTERLOCKS FL01 - FL04 - WIRING DIAGRAM	E	Jun-08
05336-D-0001	FEL / PSS DUCT SYSTEM - SITE LAYOUT	-	Oct-97
05337-D-0001	SYSTEM A / SYSTEM B INTERFACE	-	Sep-97
05338-D-0001	FEL TO MCC TRUNK CABLES - WIRING DETAILS	-	Sep-97
05339-D-0001	FEL / PSS LIGHTING CONTACTOR - WIRING DIAGRAM	-	Oct-97
05340-D-0001	FEL / PSS CONTROL ROOM CRASH SWITCH WIRING DIAGRAM	-	Oct-97
05341-D-0001	POWER / BEAM PERMIT ALARM - WIRING DIAGRAM	-	Dec-97
05342-D-0001	FEL GUN / SAFETY INTERFACE CHASSIS TEST BOX - WIRING DIAGRAM	-	1//98
05343-D-0001	¼ CRYO / SAFETY INTERFACE CHASSIS - WIRING DETAILS	-	Mar-98
05344-D-0001	¼ CRYO / SAFETY INTERFACE CHASSIS - ASSEMBLY DETAILS	-	Mar-98
05345-D-0001	¼ CRYO / SAFETY INTERFACE CHASSIS - FABRICATION DETAILS	-	Mar-98
05346-D-0001	SAFETY SYSTEM STATUS OUTPUT - WIRING DIAGRAM	A	Jan-08
05347-D-0001	PSS TO LSS INTERFACE CHASSIS - WIRING DIAGRAM	-	Oct-98
05348-D-0001	PSS TO LSS INTERFACE CHASSIS - ASEMBLY DETAILS	-	Oct-98
05349-D-0001	FEL GUN TEST STAND EQUIP LAYOUT	-	Jan-08
05350-D-0001	GTS ROLLUP DOOR WIRING DIAGRAM	-	Jan-08
05351-D-0001	GTS RUN/SAFE BOX RS01-RS02 WIRING DIAGRAM	-	Jan-08
05352-D-0001	GTS CONCRETE ACCESS DOOR WIRING DIAGRAM	-	Jan-08
05353-D-0001	GTS GUN SAFETY INTERFACE WIRING DIAGRAM	-	Jan-08
05354-D-0001	GTS GUN/SAFETY INTERFACE CHASSIS WIRING DIGRAM	-	Jan-08

April 14, 2009			
Drawing Number	Title	Revision Level	Revision Date
05355-D-0001	GTS GUN/SAFETY INTERFACE CHASSIS ASSY DETAILS	-	Jan-08
05356-D-0001	GTS GUN/SAFETY INTERFACE CHASSIS FRONT PANEL FAB DETAILS	-	Jan-08
05357-D-0001	GTS GUN/SAFETY INTERFACE CHASSIS REAR PANEL FAB DETAILS	-	Jan-08
05358-D-0001	GTS GUN/SAFETY INTERFACE CHASSIS BOTTOM PANEL FAB DETAILS	-	Jan-08
05359-D-0001	GTS CONCRETE DOOR CONTROL CIRCUIT WIRING DIAG	-	Jan-08
05360-D-0001	GTS LPSS CAVE INTERLOCKS WIRING DIAGRAM	-	Jan-08
05361-D-0001	GTS PSS/LPSS INTERFACE BOX WIRING DIAGRAM	-	Jan-08
05362-D-0001	GTS PSS/LPSS INTERFACE BOX ASSEMBLY DETAILS	-	Jan-08
05363-D-0001	GTS PSS/LPSS INTERFACE BOX FABR DETAILS	-	Jan-08
05364-D-0001	GTS LASER SAFETY INTERFACE CHASSIS WIRING DIAG	A	Apr-09
05365-D-0001	GTS LASER SAFETY INTERFACE CHASSIS ASSEMBLY DETAILS	A	Apr-09
05366-D-0001	GTS LASER SAFETY INTERFACE CHASSIS FRONT PANEL FAB DETAILS	A	Apr-09
05367-D-0001	GTS LASER SAFETY INTERFACE CHASIS REAR PANEL FAB DETAILS	-	Jan-08
05368-D-0001	GTS LASER SAFETY INTERFACE CHASSIS BOTTOM PANEL FAB DETAILS	-	Jan-08
05369-D-0001	GTS LASER/SAFETY INTERFACE WIRING DIAG	B	Apr-09
05370-D-0001	GTS I/O ALLOCATION SYSTEM A	A	Apr-09
05371-D-0001	GTS I/O ALLOCATION SYSTEM B	A	Apr-09
05372-D-0001	GTS PLC SWITCH SETTINGS AND SETUP DETAILS	A	Sep-08
05373-D-0001	GTS RADIATION MONITORS WIRING DIAGRAM	-	Jan-08
05374-D-0001	GTS RUN MODE ALARM WIRING DIAGRAM	-	Jan-08
05375-D-0001	FIRE EXIT LABYRINTH AREA WIRING DIAGRAM	A	Feb-08

April 14, 2009			
Drawing Number	Title	Revision Level	Revision Date
05376-D-0001	GTS TO FEL INTERFACE WIRING DIAGRAM	-	Jan-08
05377-D-0001	GTS LASER HUTCH SMOKE ALARM WIRING DIAGRAM	-	Jan-08
05378-D-0001	GTS LASER HUTCH SWITCH MOUNTS FABRICATION DETAILS	-	Jan-08
05379-D-0001	FEL/PSS AC POWER BREAKER LOCATIONS	-	Jan-08