


Hall A – CLEO Magnet

Aaron Brown, Brian Eng

- Continued NX12 design of sensor enclosure



NX12 model for 3D-printed enclosure base

- Total time needed for measurements is the scale from few hours to one day at most
 - ★ Removing code that was for saving power, as this is no longer needed, and the display was having issues restarting after deep sleep

Hall A – Møller

Brian Eng

- Met with Probrir to go over instrumentation and controls
 - ★ Switching all temperature sensors to PT100s
 - ★ Need a cost comparison between using PLC modules vs MSLEV chassis
 - ★ Need to identify flow meters

Hall A – SoLID

Mary Ann Antonioli, Pablo Campero, Mindy Leffel

- Wired five flanges; all six complete
- Completed modifications to PLC code to monitor the axial and radial supports sensors
 - ★ Created routines that compare each load sensor readout against warning limits and interlock limits
 - ★ Added PLC tags to allow input of the high and low limits
 - ★ Implemented routines to main PLC logic
 - ★ Added code to generate slow ramp down when axial or radial supports sensors are out of set limits
- Modified *Radial & Axial Supports – Expert* HMI screen
 - ★ Added inputs for each axial and radial support sensor to control the high and low warning and slow ramp down thresholds
 - ★ Tested modifications; no problems



Detector Support Group

We choose to do these things "not because they are easy, but because they are hard".

Weekly Report, 2022-10-26

Radial Support	Load [Kgf]	Warning Threshold		Slow Ramp Down Threshold		Enable Interlock	Warning Status	Interlock Status	Sensor Read Fault
		Low	High	Low	High				
Radial_A	158.5	:50.0	:157.6	:0.0	:150.0	Enable	Warning	●	●
Radial_B	2322	:0.0	:2400.0	:0.0	:2500.0	Enable	OK	●	●
Radial_C	785.5	:0.0	:2600.0	:0.0	:2600.0	Enable	OK	●	●
Radial_D	164.4	:0.0	:2600.0	:0.0	:2600.0	Enable	OK	●	●
Radial_E	178.8	:0.0	:2600.0	:0.0	:2600.0	Enable	OK	●	●
Radial_F	180.2	:20.0	:200.0	:0.0	:2600.0	Enable	Warning	●	●
Radial_G	2248	:0.0	:2400.0	:0.0	:2500.0	Enable	OK	●	●
Radial_H	189.3	:30.0	:2600.0	:0.0	:2600.0	Enable	Warning	●	●

Radial Support	Load [Kgf]	Low	High	Low	High	Enable Interlock	Warning Status	Interlock Status	Sensor Read Fault
Radial_J	182.0	:0.0	:2600.0	:0.0	:2600.0	Enable	OK	●	●
Radial_K	2191	:0.0	:2400.0	:0.0	:2400.0	Enable	OK	●	●
Radial_L	178.2	:0.0	:2600.0	:0.0	:2600.0	Enable	OK	●	●
Radial_M	182.0	:0.0	:2600.0	:0.0	:2600.0	Enable	OK	●	●
Radial_N	179.1	:0.0	:2600.0	:0.0	:2600.0	Enable	OK	●	●
Radial_P	175.3	:0.0	:2600.0	:0.0	:2600.0	Enable	OK	●	●
Radial_R	2333	:0.0	:2400.0	:0.0	:2400.0	Enable	OK	●	●
Radial_S	169.7	:0.0	:2600.0	:0.0	:2600.0	Enable	OK	●	●

Axial Support	Load [Kgf]	Low	High	Low	High	Enable Interlock	Warning Status	Interlock Status	Sensor Read Fault
Axial_T	1.51	:0.0	:100.0	:0.0	:200.0	Enable	OK	●	●
Axial_V	40.03	:15.0	:200.0	:10.0	:80.0	Enable	OK	●	●
Axial_W	26.52	:0.0	:2600.0	:0.0	:2600.0	Enable	OK	●	●
Axial_X	-14.1	:14.3	:4000.0	:20.0	:2600.0	Enable	OK	●	●

Solenoid Radial & Axial Support – Expert HMI screen

Hall B – Magnets

Brian Eng

- Solenoid fast dump: <https://logbooks.jlab.org/entry/4067563>
 - ★ No obvious causes; the sequence of events module lost communication and needed to be power cycled

Hall C – NPS

Mary Ann Antonioli, Peter Bonneau, Aaron Brown, Brian Eng, Tyler Lemon, Marc McMullen

- Completed fabrication of humidity sensor power distribution panel
 - ★ Discussed with Brad Sawatzky the design of, and connections to, the +5 V power distribution box for the relative humidity sensors
 - ★ The cable from the power supply to the distribution panel will be 8-conductor (four twisted pairs) terminated with an 8-pin connector
- Began low voltage Phoebus screen
- Reviewing the Phoebus screens manual
- Reviewing documentation of the VME LED Driver (VLD) module
- Discussed procedure to test Phoebus screens, set up computer for testing, and began testing the *Front Crystal Zone Temperature Monitoring* screen
 - ★ Contacted computer center to move the Keysight mainframe and the NPS cRIO from the Hall B development subnet to the Hall C development subnet
 - ★ Copied the hardware interlock LabVIEW program to the NPS cRIO; verified that program runs correctly
 - ★ Installed CSS-Phoebus software on computer

Detector Support Group

We choose to do these things "not because they are easy, but because they are hard".

Weekly Report, 2022-10-26

- Will provide a simplified version of the hardware interlock LabVIEW program for NPS testing in the EEL building
 - ★ The ability to disable sensors will be removed
- Tested 12 relative humidity sensors to be used for NPS – the readback of all 12 sensors' relative humidity was within 2–3% of the control relative humidity sensor
- Developing test IOC on DSG development PC for MPOD low voltage communication to EPICS
 - ★ Investigating how to add SNMP command capabilities (how MPODs communicate over the network) to an EPICS IOC

Hall D – JEF

Mindy Leffel

- Wrapped eight crystals

EIC


Pablo Campero, Brian Eng, George Jacobs, Marc McMullen

- Beampipe PR was delayed; assigned buyer on 10/25

EIC - DIRC

Tyler Lemon, Marc McMullen, Peter Bonneau

- Met with DIRC group to discuss laser room infrastructure and interlock system
- Laser interlock system circuit
 - ★ Latest system will use a timed relay for laser enable contacts
 - ★ Has keyed switch for allowing control from and lockout of an exterior control panel
 - Exterior control panel will duplicate *immediate status, latched status, reset active, bypass active*, and reset button so it can be seen from outside of laser area
 - ★ Compiling list of parts and instrumentation needed for laser interlock system



Laser interlock controls diagram



Detector Support Group

We choose to do these things "not because they are easy, but because they are hard".

Weekly Report, 2022-10-26

- Investigating more readily available instrumentation for photodiode data acquisition
 - ★ National Instruments and Keithley options have ~16 week lead times
 - ★ Can receive an Arduino external ADC and display in 2-3 weeks from ordering
- Submitted the laser task hazard analysis, laser operating procedure, and laser specific training plan to Laser Safety Officer Jenn Williams for review